# **PRIOR** YOUR TANNING SESSION



Before starting your tanning session, the touch screen allows you to choose certain tanning options in advance. Simply select your preferences and enjoy your tanning session from the very beginning.

## ICON STATUS





light gray inactive



not available

## **BASIC INSTRUCTIONS**





Design by STUDIO F-A-PORSCHE

# **DURING THE TANNING SESSION**



## INTERIOR CONTROL PANEL

You can control the functions via the interior control panel during the tanning session. It is particularly easy for you to access the basic functions. Additionally, you can also change the subordinate functions settings by using the interior control panel.

Buttons - Control the functions

Arrow Buttons – Select the subordinate function, as Aroma, Voice, aircon, Audio or Aqua

START – Starts the tanning session

STOP – Stops the tanning session if pressed for at least two seconds

# **FUNCTIONS** OF THE EXTERIOR AND INTERIOR



#### SUN - TANNING LEVEL

Optimum tanning conditions suited to meet the requirements of individually different pretan levels are achieved by specifically adapting the UV spectrum.

#### SENSITIV

For the first tanning session in a while or customers with very fair skin.

### **MEDIUM**

Develops a natural and beautiful looking tan for each skin type.

#### **INTENSIV**

The optimal tanning performance you can achive within all regulatory guidelines.



## **AUDIO - MUSIC SELECTION**

You can pre select one out of three different audio sources.

### **SOLARIUM (MP3-INTERN)**

During the tanning session, you will listen to the tracks played by the internal MP3 player of the tanning device.

#### SALON (STUDIO)

You will listen to the music that is provided externally by the studio operator.

### **BLUETOOTH (MP3-EXTERN)**

Connect your smartphone via bluetooth and enjoy your personal playlists.

OFF - Musik off.



**MEGAVOICE** – Switches the voice guidance (megaVoice) on or off.



AROMA – Switches the aroma on or off.



AIRCON – Switches the aircon unit on or off.



AQUA - Switches the aquaCool function on or



BODY TAN – The body fan is automatically the fan buttons, the automatic mode is interrupted.



BEAUTY BOOSTER - Change the intensity or switch off.



IIIIIIIIIII GLASS FACIAL SYSTEM - Change the intensity or switch off.



**VOLUME** – Change the volume.

